

## OEM REFINISHING SYSTEM

## **TIME COMPARISON**

FOR FINISHING NEW RADIATOR SUPPORT

## USING SEM OEM REFINSHING SYSTEM

Process	Minutes
Move Car to Booth	0
Prep	6
Wait on Painter	0
Mix All Primer & Paint	0
Apply Ez Coat	3
Flash Time	0
Clean Gun	0
Apply Factory Pack	6
Flash Time	0
Clean Gun	0
Apply 1K HS Clear (optional)	3
Flash Time	0
Clean Gun	0
Move Car Back to Shop	0

**Total** 

## USING TRADITIONAL METHOD

Process	Minutes
Move Car to Booth	10
Prep	6
Wait on Painter	0 – ?
Mix All Primer & Paint	10
Apply Primer/Sealer	3
Flash Time	30
Clean Gun	2
Apply Basecoat Color	6
Flash Time	30
Clean Gun	2
Apply Clear (optional)	3
Flash Time	15
Clean Gun	2
Move Car Back to Shop	10
Total	129 Minutes



**18 Minutes**