

4020 Overhead Creeper

Made In USA

CHAMP[®]

Frame Straightening Equipment Inc.



WARNING

Read all assembly instructions completely before attempting to assemble unit. Improper assembly could result in damage to unit or injury to user.

Auto Body Toolmart

Champ Frame Straightening Equipment, Inc.

2545 Millennium Dr., Elgin, IL 60124 (800) 382-1200

www.autobodytoolmart.com

1.



Overhead Creeper is completely assembled.

2.



To lock into working position: Lift pad & step assembly

3.



Lift support arm. Remove locking pin from Pad & Step Assembly. Position support arm into Pad & Step Assembly and insert locking pin. This will lock support arm into place. Repeat for other side.



The Overhead Creeper is now ready to use.