


# 4017 Adjustable Paint/Work Ladder

Made In USA



## Parts List

- A** 1 - Support Base
- B** 1 - Steps
- C** 2 - Wheels
- D** 2 - Nuts and Bolts (for wheels)



### WARNING

Read all assembly instructions completely before attempting to assemble unit. Improper assembly could result in damage to unit or injury to user.

**Auto Body Toolmart**

**Champ Frame Straightening Equipment, Inc.**

2545 Millennium Dr., Elgin IL, 60124 (800) 382-1200

[www.autobodytoolmart.com](http://www.autobodytoolmart.com)

1.



Unscrew the nut and remove the bolt from part A on each side. Line up the holes on part A and Part B. Keep Part B in an upright position.

2.



Insert the bolt on each side into the aligned holes and tighten the nut. Repeat for other side.

3.



Remove the nuts and bolts on the side support. Adjust the side support so the holes align. Insert the bolt and tighten the nut on each side. Repeat for other side.

4.



Place the wheels on the back of the base. Insert the bolt and tighten the nut.

The Adjustable Paint/Work Ladder is now ready to be used.

