

# 1836 Champ PDR Lighting System


Made In USA



## Parts List

- A** 1 - Base
- B** 1 - 47" Tube
- C** 1 - 53" Inner Tube
- D** 1 - Light Holder
- E** 1 - Light Handle
- F** 3 Wheels With 1/2" Nut
- G** 1 - Light Fixture (requires 2 48" Cool White Bulbs - Not Included)
  - \*1 - 1/4 X 2" Push Pin
  - \*1 - 1/4 X 1 1/2" Screw
  - \*2 - 1/4 X 2" Screws
  - \*3 - 5/16" Hand Knobs
  - \*1 - #10 X 1 1/4" Screw & Nut

**Note:** Bolts, nuts & hand knobs  
are pre-installed



## WARNING

Read all assembly instructions completely before attempting to assemble unit.  
Improper assembly could result in damage to Light or injury to user.

Auto Body Toolmart

Champ Frame Straightening Equipment, Inc.

2545 Millennium Dr. Elgin, IL 60124 (800) 382-1200

[www.autobodytoolmart.com](http://www.autobodytoolmart.com)

**1.**

Unfasten the two screws in the base and insert the leg. The holes will align.

**2.**

Insert the screws into each hole of the base.

**3.**

There are 3 holes at the end of each side of the base. Unscrew the nuts on the wheels and insert a wheel on each side of the base. Tighten the screws on the wheels.

**4.**

Insert the 47" metal tube into the base and tighten the knob to keep the tube steady.


**5.**

Insert the 53" inner tube into the 47" tube.

**6.**

The height of the inner tube can be adjusted by placing it at the desired height and tightening the knob.

7.



Take out the screw and insert the light holder. It will rest on a push pin and be held in place when you reinsert the screw and tighten the nut.

9.



Take out the screw on the light. Insert the light on the end of the handle. Align the hole on the handle with the one on the light.

8.



Insert the light handle into the light holder. The handle should go all the way through the holder until you see a hole for a screw come out the other end. Tighten the knob to keep the handle in place.

10.



Reinsert the screw and tighten the nut.

11.



The Champ PDR Lighting System is now ready to be used. The light can be adjusted by loosening the knob on the light and swiveling to desired angle. The height can be adjusted by loosening the knob on the inner tube and raising the light to the desired height.